

Supplement for Pandora®

The Pandora service is available in the U.S.A., Australia and New Zealand only.

Notes

- Configure basic settings for the MusicCast CONTROLLER app before using the service.
- To use this function, the unit must be connected to the Internet. For detail on connections and network settings, refer to "Owner's Manual".

Pandora is a free, personalized Internet radio service playing only music you love. Enter your favorite artists or tracks and Pandora will bring an effortless personal soundtrack into your living room. Rate tracks as they play, because Pandora caters to your tastes and adapts stations to your feedback on the spot.

Since all Pandora accounts are portable, you can always access your own personalized Pandora stations from any computer or device in the United States, Australia and New Zealand that supports Pandora.

Pandora is currently only available within these countries due to licensing restrictions. Pandora is always free, with the option to upgrade to Pandora One which is completely free of all advertising and comes with additional features.

For more information, <http://www.pandora.com>

Pandora account sign-in

To start using the Pandora service on this unit, sign in to your account using the MusicCast CONTROLLER app installed on your mobile device. Follow the instructions on the app screen.

Playback of Pandora content

Use the MusicCast CONTROLLER app installed on your mobile device to select the Pandora service.