


Practice Chanter

— Assembly Instructions —

Always grasp the chanter and blowpipe near where they join to assemble or disassemble the practice chanter. Never grasp the practice chanter by the sole when putting the pieces together or taking them apart. You can break a chanter at its neck by doing this.

1. Insert the reed into the chanter as shown. To avoid damaging the reed, hold it **ONLY** by its wrapped staple; **NEVER** by the white blades. Twist reed firmly into place so that it sits straight.
2. Carefully slide the blowpipe over the reed and onto the chanter. If the reed touch the inside wall of the blowpipe it will not sound, and may be damaged.
3. Twist the two pieces firmly together. If the chanter does not play, the reed may have come loose.




— Storage —

After each practice session take the practice chanter apart and shake out any moisture. Store in a dry area and away from direct sunlight.

See reverse for playing instructions.

— Finger Placement Diagram —

The diagram below shows the correct finger positions for playing your practice chanter. Place your hands (left hand on top, right hand on bottom) on the chanter with your fingers straight. This is called the "Piper's Grip".



Playing a scale: To play the scale below, cover the holes where black dots are shown.

