


Caring for your Cuica

Do not let the head get damp, and always protect it from sharp objects. Pulling too hard, or holding the stick too tight, may dislodge or break the stick. There is no warranty on the stick, but if the stick does break, you can easily replace it. Look for bamboo skewers in the grocery store. A small amount of glue will hold it in place.

Here are some simple tips to care for your cuica:

- Use a dry soft cloth for dusting
- Avoid extreme heat, cold, dry conditions and direct sunlight
- Avoid using abrasives



Cuica Head
CUIH5
(sold separately)

Accessories

More drums, heads and accessories are available at www.mid-east.com



www.mid-east.com

© Copyright 2015. Mid-East Mfg. Inc.
Cuica

DOBANI™

CUICA




– OWNER'S GUIDE –

Caring for your Cuica

Do not let the head get damp, and always protect it from sharp objects. Pulling too hard, or holding the stick too tight, may dislodge or break the stick. There is no warranty on the stick, but if the stick does break, you can easily replace it. Look for bamboo skewers in the grocery store. A small amount of glue will hold it in place.

Here are some simple tips to care for your cuica:

- Use a dry soft cloth for dusting
- Avoid extreme heat, cold, dry conditions and direct sunlight
- Avoid using abrasives



Cuica Head
CUIH5
(sold separately)

Accessories

More drums, heads and accessories are available at www.mid-east.com



www.mid-east.com

© Copyright 2015. Mid-East Mfg. Inc.
Cuica

DOBANI™

CUICA



– OWNER'S GUIDE –

DOBANI™ Cuica

How to Play

Hold the cuica so you can reach inside with one hand, while the thumb or finger of the opposite hand is free to manipulate the head. Lightly pinch the bamboo stick with a wetted sponge or cloth. Now rub the stick. Dragging the sponge up and down the stick will vibrate the head and produce the most delightful sounds. To alter the pitch, press one finger as close to the center of the head as possible; the harder you press the higher the pitch. First practice the basic tempo. Rub the stick up and down while counting. Play all low tones, do not press the head. Then Samba, by alternating the pitch High to Low by applying and removing pressure on the head.

Basic count 1 & 2 & 1 & 2 &
High pitch
 Low pitch L L L L L L L L

Samba 1 & 2 & 1 & 2 &
High pitch H H H H
 Low pitch L L L L

Variation 1 & 2 & 1 & 2 & 1 & 2 & 1 & 2 &
High pitch HH HH HH HH
 Low pitch L LL LL LL L

Variation 1 & 2 & 1 & 2 & 1 & 2 & 1 & 2 &
High pitch HH HH HH
 Low pitch L LL LL LLLLL

DOBANI™ Cuica

How to Play

Hold the cuica so you can reach inside with one hand, while the thumb or finger of the opposite hand is free to manipulate the head. Lightly pinch the bamboo stick with a wetted sponge or cloth. Now rub the stick. Dragging the sponge up and down the stick will vibrate the head and produce the most delightful sounds. To alter the pitch, press one finger as close to the center of the head as possible; the harder you press the higher the pitch. First practice the basic tempo. Rub the stick up and down while counting. Play all low tones, do not press the head. Then Samba, by alternating the pitch High to Low by applying and removing pressure on the head.

Basic count 1 & 2 & 1 & 2 &
High pitch
 Low pitch L L L L L L L L

Samba 1 & 2 & 1 & 2 &
High pitch H H H H
 Low pitch L L L L

Variation 1 & 2 & 1 & 2 & 1 & 2 & 1 & 2 &
High pitch HH HH HH HH
 Low pitch L LL LL LL L

Variation 1 & 2 & 1 & 2 & 1 & 2 & 1 & 2 &
High pitch HH HH HH
 Low pitch L LL LL LLLLL